



Handling and Storage

1. Johnsonite flooring and adhesives must be site conditioned at room temperature for 48 hours prior to, during, and after installation. Room temperature must be maintained between 65° and 85°F (18° and 30°C) with HVAC system operating. A minimum temperature of 55°F (13°C) must be maintained afterwards. The ambient relative humidity should be between 40% and 60%.
2. In areas that are exposed to intense or direct sunlight, the product must be

protected during the conditioning, installation, and adhesive curing periods, by covering the light source.

3. The highest quality of materials and workmanship is employed in the manufacture of Johnsonite Flooring and careful inspection is made before shipment. However, a quality installation is the responsibility of the installer. It is the installer's responsibility to verify the accuracy of the order and to ensure the materials are checked for damage,

defects, and satisfactory color match. An authorized Johnsonite distributor or Johnsonite representative must be notified of any defects before installation proceeds.

4. Johnsonite cannot accept responsibility for any loss or damage that may result from the use of this information, due to processing or working conditions and/or workmanship outside our control. Users are advised to confirm the suitability of this product by their own tests.

General Subfloor Preparation

1. **All subfloors** must be clean, smooth, flat and dry. The surface must be free of all dust, loose particles, solvents, paint, grease, oil, wax, alkali, sealing/curing compounds, old adhesive, and any other foreign material, which could affect installation. **Caution: Do not use oil based sweeping compounds.** Fill all depressions, cracks, and other surface irregularities with a good quality Portland cement based underlayment patching compound.

NOTE: Contamination on the substrate can cause damage to the resilient flooring material. Permanent and non-permanent markers, pens, crayons, paint, etc., must not be used to write on the back of the flooring material or used to mark the substrate as they could bleed through and stain the flooring material. If these contaminants are present on the substrate they must be mechanically removed prior to the installation of the flooring material.

Caution: Do not use liquid solvents or adhesive removers.

Johnsonite does not recommend installing over existing resilient floors. All existing flooring and adhesives must be removed prior to installing the new flooring material. Remove existing adhesive mechanically – do not use chemical adhesive removers or solvents.

Caution: Some resilient flooring products and adhesives contain "asbestos fibers" and special handling of this material is required.

2. **Concrete subfloors** must be constructed as recommended by the American Concrete Institute's ACI 302.2 "Guide for Concrete Slabs that Receive Moisture-Sensitive Flooring Materials" and prepared to receive resilient flooring according to ASTM F 710 "Standard

Practice for Preparing Concrete Floors to Receive Resilient Flooring".

Do not install Johnsonite flooring over expansion joints.

All concrete subfloors must be tested for moisture and pH (alkalinity):

Moisture testing must be conducted in accordance with ASTM F 2170 "Standard Test Method for Determining Relative Humidity in Concrete Floor Slabs using *in situ* Probes" or ASTM F 1869 "Standard Test Method for Measuring Moisture Vapor Emission Rate of Concrete Subfloor Using Anhydrous Calcium Chloride.

Results must not exceed 80% when testing to ASTM F 2170 or exceed 5 lbs. per 1,000 sq. ft. in 24 hours when testing to ASTM F 1869.

If the tests results exceed the limitations, the installation must not proceed until the problem has been corrected.

A pH test for alkalinity must be conducted. Results should range between 7 and 9. If the test results are not within the acceptable range of 7 to 9, the installation must not proceed until the problem has been corrected.

3. **Wood subfloors** must have a minimum 18" (47 cm) of cross-ventilated space between the bottom of the joist and ground. Exposed earth crawl spaces should be sealed with a polyethylene moisture barrier.

Subfloors should meet local and national building codes. Trade associations, such as the APA "The Engineered Wood Association", offer structural guidelines for meeting various code requirements.

Single Wood and Tongue and Groove subfloors should be covered with 1/4" (6.4 mm) or 1/2" (13 mm) APA approved underlayment plywood. Use 1/4" (6.4 mm) thick underlayment panels for boards with a face width of 3" (76 mm) or less. For boards wider than 3" (76

mm) face width use 1/2" (13 mm) underlayment panels.

Countersink nail heads and fill depressions, joints, cracks, gouges, and chipped edges with a good quality Portland cement based patching compound.

Do not install over OSB (Oriented Strand Board), particle board, chipboard, lauan or composite type underlayments.

4. **Terrazzo and Ceramic floor** surface must be thoroughly sanded to remove all glaze and waxes. Remove or replace all loose tiles and clean the grout lines. Use a Portland cement based leveling compound to fill all grout lines and other depressions.

5. **Steel floor** surface must be mechanically abraded to assist with the adhesive bond. The floor must be cleaned to remove all dirt, rust and other contaminants. Surface must be coated with a rust inhibitor / primer. When applying adhesive the non-porous installation instructions must be followed.

6. **Concrete floors equipped with a radiant heating system:** Turn the heat down to 65°F (18°C) for at least 48 hours before installation. Heat may be gradually returned to operating temperature 48 hours after installation. Temperature should not exceed 85°F (30°).

7. **An adhesive bond test** should be performed using the actual flooring materials and adhesive to be installed. The test areas should be a minimum of 36" x 36" and remain in place for at least 72 hours and then evaluated for bond strength to the concrete.



Luxury Vinyl Tile and Planks Installation

1. Recommended Adhesives:

- a.** For standard application use:
Johnsonite 926 Vinyl Flooring Adhesive
Trowel: porous and non-porous substrates –
1/32" x 1/16" x 1/32" U-notch
Approximate coverage: 250 to 300 sq. ft. per gallon.

Note: Determine substrate porosity and follow the adhesive label instructions regarding proper adhesive open time.

- b.** For application in areas subject to heavy point loads, rolling loads, topical moisture, or temperature extremes use:
Johnsonite 975 Two-Part Urethane Adhesive
Trowel: porous and non-porous substrates –
1/32" x 1/16" x 1/32" U-notch
Approximate coverage: 225 to 250 sq. ft. per gallon.

Caution: When installing with 975 Two-Part Urethane Adhesive the installer must work off of the flooring material to prevent adhesive displacement during the installation and rolling process.

- c.** SpraySmart Adhesive System:
SpraySmart 150 Specialty Flooring Spray Adhesive
Approximate coverage: 150 to 185 sq. ft. per 22oz. can.

The SpraySmart Adhesive System is unique; instructions on can must be followed.

Note: Contact Johnsonite Technical Department prior to use for training.

- 2. Adhesive Application:** Follow adhesive label instructions for proper use.

3. Floor Installation Procedure:

- a.** Batch numbers should not be mixed during the installation.
b. Square the area and establish reference points on the substrate.
c. Apply the adhesive to the substrate and allow proper open time.
d. Use established reference points and install the flooring.
e. Install **Planks** in the same direction, in a random pattern, and offset plank end joints by 6" (15.2 cm).
f. Install **Tiles** with the directional arrows (found on the back on each tile) pointing in the same direction. Tiles may be 'quarter-turned' to create a pattern.

- g.** Planks and Tiles should be lightly butted together when placing the flooring into the adhesive.

- h.** Do not force Planks or Tiles together creating a ledge condition at the seams and corners.

- i.** When using 975 Two-Part Urethane Adhesive the installer **MUST** work off the flooring. Sliding tiles will result in forcing the adhesive out between the seams.

- j.** Periodically, lift the corner of an installed tile or plank to ensure proper transfer of adhesive.

- k.** Roll floor in both directions with a 100 pound three-section roller. Use a small hand roller in areas that cannot be reached with a large roller.

- l.** Inspect the floor surface, especially seams, and remove any adhesive on the surface.

4. Traffic:

- a.** All traffic must be restricted for 24 hours after installation.
b. No heavy traffic, rolling loads, or furniture placement for 72 hours after installation.

Adhesive Clean Up

Excess adhesive should be removed during the installation process.

926 Vinyl Flooring Adhesive

- ◆ Use a clean white cloth dampened with water to remove wet adhesive from floor covering and tools.
- ◆ Dried adhesive may require the use of denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)

975 Two-Part Urethane Adhesive

- ◆ Before the adhesive sets, remove excess adhesive from flooring and clean tools with denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)
- ◆ Do not allow adhesive to dry on the flooring surface.
- ◆ Removing dried adhesive may cause irreparable damage to the flooring surface.

SpraySmart 150 Specialty Flooring Spray Adhesive

- ◆ Use a clean white cloth dampened with water to remove wet adhesive from floor covering and tools.
- ◆ Dried adhesive may require the use of denatured alcohol applied to a clean white cloth. (Follow manufacturer's precautions when using denatured alcohol.)

Maintenance

1. Wait 72 hours after installation before performing initial cleaning.
2. A regular maintenance program must be started after the initial cleaning.
3. Refer to Johnsonite's Maintenance Instructions for complete details.

Visit www.johnsonite.com for most current installation and maintenance instructions. Contact Johnsonite Technical Services at (800)-899-8916 ext 9297 with any questions.



THE ULTIMATE
FLOORING EXPERIENCE

Technical Services Department
16910 Munn Road, Chagrin Falls, Ohio 44023
(800) 899-8916 ext 9297 Fax (440) 632-5643
www.johnsonite.com
email: info@johnsonite.com
© 2013 Johnsonite Inc.